

SAND BAG DISTRIBUTION PROGRAM

How do I sandbag my home correctly?

Sandbags alone only provide for limited flood support.

1. Visqueen or sheet plastic should be placed on the opening in a “L” position secured by tape on the top and sides of the opening, approximately 24” from the bottom of the opening in both directions and 6”-12” on each side.
2. Filled sandbags should be placed horizontally on top of the plastic, in a row, tightly touching both sides of the opening and can be stacked vertically as needed.

